

APPLICATION OF CUT-OUT 3M STICKERS

You need: 1 Plastic spatula or a piece of firm plastic such as a 3.5" computer diskette (!) - no sharp edges !!
1 clean soft cloth about 3 times as big as the spatula
1 narrow "Japan" or "carpet cutting" type cutting knife with a new blade

1. The surface should be clean but not polished. Do not use cleaners which contain silicon !! We recommend AJAX (or similar) window / glass cleaner!
2. Individual "Cheetah" stickers do not need to be cut out, because they are already pre-cut out. If you receive several stickers on a single sheet, cut them out from the sheet leaving a little spare paper around the edges.
3. Remove the sticker's backing paper.
4. Carefully position the sticker in place and then, from the center outwards, use the plastic spatula to gently press the sticker into place.
5. Wrap the spatula in the cloth, in order to protect the edges.
6. Press the sticker properly into place from the centre outwards. This will press any air bubbles out to the edges.
7. In order to get rid of small air bubbles which cannot be pressed out, make a very small (max. 0,5 mm) cut with the knife, press the air out and press the cut edges down FIRMLY.
NEVER USE A PIN TO GET RID OF AIR BUBBLES!!
When you use a knife, the cut edges will practically bond together again and be invisible.
Pins leave small, visible, ugly craters which let in air and water.